PARTS LIST

Index No.	Part Number	Description
1	*CI006	WINDOW RETAINING TAB
2	R3678	WINDOW (BLACK PAINT)
2	R3688	WINDOW (BLACK ENAMEL)
2	R3696	WINDOW (SAND ENAMEL)
2	R3704	WINDOW (GREEN ENAMEL)
2	R3712	WINDOW (RED ENAMEL)
2	R3720	WINDOW (NAVY ENAMEL)
3	R3723	GRILL - LEFT (BLACK PAINT)
3	R3726	GRILL - LEFT (BLACK ENAMEL)
3	R3729	GRILL - LEFT (SAND ENAMEL)
3	R3732	GRILL - LEFT (GREEN ENAMEL)
3	R3735	GRILL - LEFT (RED ENAMEL)
3	R3738	GRILL - LEFT (NAVY ENAMEL)
4	R3724	GRILL - CENTER (BLACK PAINT)
4	R3727	GRILL - CENTER (BLACK ENAMEL)
4	R3730	GRILL - CENTER (SAND ENAMEL)
4	R3733	GRILL - CENTER (GREEN ENAMEL)
4	R3736	GRILL - CENTER (RED ENAMEL)
4	R3739	GRILL - CENTER (NAVY ENAMEL)
5	R3725	GRILL - RIGHT (BLACK PAINT)
5	R3728	GRILL - RIGHT (BLACK ENAMEL)
5	R3731	GRILL - RIGHT (SAND ENAMEL)
5	R3734	GRILL - RIGHT (GREEN ENAMEL)
5	R3737	GRILL - RIGHT (RED ENAMEL
5	R3740	GRILL - RIGHT (NAVY ENAMEL)
6	R3673	TOP (BLACK PAINT)
6	R3683	TOP (BLACK ENAMEL)
6	R3691	TOP (SAND ENAMEL)
6	R3699	TOP (GREEN ENAMEL)
6	R3707	TOP (RED ENAMEL)
6	R3715	TOP (NAVY ENAMEL)

PARTS LIST

Index No.	Part Number	Description
7	* CI007	RETAINING TAB - 4 REQUIRED
8	R3675	SIDE - RIGHT (BLACK PAINT)
8	R3685	SIDE - RIGHT (BLACK ENAMEL)
8	R3693	SIDE - RIGHT (SAND ENAMEL)
8	R3701	SIDE - RIGHT (GREEN ENAMEL)
8	R3709	SIDE - RIGHT (RED ENAMEL)
8	R3717	SIDE - RIGHT (NAVY ENAMEL)
9	R3677	FRONT (BLACK PAINT)
9	R3687	FRONT (BLACK ENAMEL)
9	R3695	FRONT (SAND ENAMEL)
9	R3703	FRONT (GREEN ENAMEL)
9	R3711	FRONT (RED ENAMEL)
9	R3719	FRONT (NAVY ENAMEL)
10	* CI009	LEG PAD “B” - 2 REQUIRED
11	* CI008	LEG PAD “A” - 2 REQUIRED
12	* R3747	LEVELING BOLT - 4 REQUIRED
13	R3741	LEG - 4 REQUIRED (BLACK PAINT)
13	R3742	LEG - 4 REQUIRED (BLACK ENAMEL)
13	R3743	LEG - 4 REQUIRED (SAND ENAMEL)
13	R3744	LEG - 4 REQUIRED (GREEN ENAMEL)
13	R3745	LEG - 4 REQUIRED (RED ENAMEL)
13	R3746	LEG - 4 REQUIRED (NAVY ENAMEL)
14	R3674	SIDE - LEFT (BLACK PAINT)
14	R3684	SIDE - LEFT (BLACK ENAMEL)
14	R3692	SIDE - LEFT (SAND ENAMEL)
14	R3700	SIDE - LEFT (GREEN ENAMEL)
14	R3708	SIDE - LEFT (RED ENAMEL)
14	R3716	SIDE - LEFT (NAVY ENAMEL)

*PART IS NOT SUPPLIED WITH CASTING, IT IS INCLUDED IN THE FIREBOX HARDWARE PACKAGE

CIFB-1 CIPS-1
CIPB-1 CIPN-1
CIPG-1 CIPR1

Click Part # To View Price & Availability

STOVE CASTING

MODELS: CIFB-1, CIPB-1, CIPG-1, CIPS-1, CIPN-1, CIPR-1



CIFB-1	**CIPS-1**
CIPB-1	**CIPN-1**
CIPG-1	**CIPR1**

PARTS LIST

Index No.	Part Number	Description
1	R3436	REMOTE/OFF/ON SWITCH
2	CI199	WIRE CHANNEL ASSEMBLY
3	CI198	REAR COVER
4	CI188	OUTLET BAFFLE
5	CI247	INNER TOP
6	CI189	INNER TOP FACE
7	CI192	REFLECTOR
8	CI030	INNER BODY
9	CI190	REAR LOG SUPPORT ASSEMBLY
10	CI196	SCREEN FRAME ASSEMBLY
11	R2708	PIEZO IGNITOR
12	CI068	VALVE COVER ASSEMBLY
13	CI253	MAGNET ASSEMBLY (2 REQUIRED)
14	*CI008	LEG PAD-A (2 REQUIRED)
15	*CI009	LEG PAD-B (2 REQUIRED)
16	CI028	INNER BOTTOM FACE
17	CI031	LOCATION WASHER (2 REQUIRED)
18	CI347	LOG SUPPORT
19	R3625	GAS VALVE - LPG
19	R3626	GAS VALVE - NAT
20	P8654	ORIFICE-LPG
20	P8640	ORIFICE-NAT
21	CI176	MANIFOLD ASSEMBLY
22	CI023	BURNER BRACKET - RIGHT
23	CI184	AIR SHUTTER BODY - NAT
23	CI185	AIR SHUTTER BODY - LPG
24	R3612	BURNER
25	R3623	PILOT ASSEMBLY - LPG WITH THERMOPILE AND THERMOCOUPLE
25	R3624	PILOT ASSEMBLY - NAT WITH THERMOPILE AND THERMOCOUPLE
26	CI180	PILOT TUBING
27	CI166	BURNER BRACKET - LEFT
28	CI193	FRONT LOG SUPPORT ASSEMBLY
29	R3642	FRONT LOG
30	R3644	TOP LOG
31	R3643	REAR LOG
Not Shown	R1266	THERMOSTAT
Not Shown	R2789	IGNITOR WIRE
Not Shown	*R3747	LEVELING BOLT (4 REQUIRED)
Not Shown	*CI007	RETAINING TAB (4 REQUIRED)
Not Shown	R3765	WIRE ASSEMBLY
Not Shown	*CI006	WINDOW RETAINING TAB

* PART IS INCLUDED IN THE HARDWARE PACKAGE AND IS USED IN THE ASSEMBLY OF THE STOVE CASTING



CIVF-25-1

Click Part # To View Price & Availability

PARTS LIST

Index No.	Part Number	Description
1	R3436	REMOTE/OFF/ON SWITCH
2	CI326	SWITCH BOX
3	CI328	WIRE CHANNEL
4	CI335	REAR COVER
5	CI188	OUTLET BAFFLE
6	CI287	INNER TOP
7	CI391	REFLECTOR
8	CI280	INNER BODY
9	CI380	SCREEN FRAME ASSEMBLY
10	R2708	PIEZO IGNITOR
11	CI068	VALVE COVER ASSEMBLY
12	CI253	MAGNET ASSEMBLY (2 REQUIRED)
13	* CI008	LEG PAD-A (2 REQ'D)
14	* CI009	LEG PAD-B (2 REQ'D)
15	CI288	INNER BOTTOM FACE
16	CI181	INNER BOTTOM ASSEMBLY
17	R3625	GAS VALVE - LPG
17	R3626	GAS VALVE - NAT
18	P8654	ORIFICE-LPG
18	P8640	ORIFICE-NAT
19	CI176	MANIFOLD ASSEMBLY
20	CI023	BURNER BRACKET - RIGHT
21	CI258	AIR SHUTTER BODY - NAT
21	CI259	AIR SHUTTER BODY - LPG
22	R3612	BURNER
23	R3623	PILOT ASSEMBLY-LPG
23	R3624	PILOT ASSEMBLY-NAT
24	CI180	PILOT TUBING
25	CI166	BURNER BRACKET - LEFT
26	CI347	LOG SUPPORT ASSEMBLY
27	CI351	LOG SUPPORT BAFFLE
28	R3642	FRONT LOG
29	R3644	TOP LOG
30	R3643	REAR LOG
NOT SHOWN	CI348	SWITCH BOX INSULATION
NOT SHOWN	R5668	ELECTRODE WIRE
NOT SHOWN	* R3747	LEVELING BOLT (4 REQUIRED)
NOT SHOWN	* CI007	RETAINING TAB (4 REQUIRED)
NOT SHOWN	R3765	WIRE ASSEMBLY

*PART IS INCLUDED IN THE HARDWARE PACKAGE AND IS USED IN THE ASSEMBLY OF THE STOVE CASTING



CIVF-25-2

Click Part # To View Price & Availability

PARTS LIST

Index No.	Part Number	Description
1	R3436	REMOTE/OFF/ON SWITCH
2	CI326	SWITCH BOX
3	CI328	WIRE CHANNEL
4	CI335	REAR COVER
5	CI188	OUTLET BAFFLE
6	CI287	INNER TOP
7	CI391	REFLECTOR
8	CI280	INNER BODY
9	CI380	SCREEN FRAME ASSEMBLY
10	R2708	PIEZO IGNITOR
11	CI068	VALVE COVER ASSEMBLY
12	CI253	MAGNET ASSEMBLY (2 REQUIRED)
13	* CI008	LEG PAD-A (2 REQ'D)
14	* CI009	LEG PAD-B (2 REQ'D)
15	CI288	INNER BOTTOM FACE
16	CI181	INNER BOTTOM ASSEMBLY
17	R3625	GAS VALVE - LPG
17	R3626	GAS VALVE - NAT
18	P8654	ORIFICE-LPG
18	P8640	ORIFICE-NAT
19	CI176	MANIFOLD ASSEMBLY
20	CI023	BURNER BRACKET - RIGHT
21	CI258	AIR SHUTTER BODY - NAT
21	CI259	AIR SHUTTER BODY - LPG
22	R5278	BURNER
23	R3623	PILOT ASSEMBLY-LPG
23	R3624	PILOT ASSEMBLY-NAT
24	CI180	PILOT TUBING
25	CI166	BURNER BRACKET - LEFT
26	CI347	LOG SUPPORT ASSEMBLY
27	CI351	LOG SUPPORT BAFFLE
28	R3862	FRONT LOG
29	R3864	TOP LOG
30	R3863	REAR LOG
NOT SHOWN	CI348	SWITCH BOX INSULATION
NOT SHOWN	R5668	ELECTRODE WIRE
NOT SHOWN	* R3747	LEVELING BOLT (4 REQUIRED)
NOT SHOWN	* CI007	RETAINING TAB (4 REQUIRED)
NOT SHOWN	R3765-A	WIRE ASSEMBLY
NOT SHOWN	M166	MANIFOLD ORIFICE GASKET

*PART IS INCLUDED IN THE HARDWARE PACKAGE AND IS USED IN THE ASSEMBLY OF THE STOVE CASTING



CIVF-25-3

Click Part # To View Price & Availability

PARTS LIST

Index No.	Part Number	Description
1	15516	VALVE COVER ASSEMBLY
2	15566	INNER BOTTOM ASSEMBLY
3	R5701	GAS VALVE - LPG
3	R5700	GAS VALVE - NAT
4	R2423	BRASS MALE CONNECTOR
5	15557	TUBING - VALVE TO BURNER
6	15567	SCREEN FRAME ASSEMBLY
7	P253	ORIFICE FITTING
8	P185	ORIFICE - LPG
8	P243	ORIFICE - NAT
9	R3357	SPRING
10	15560	AIR SHUTTER - NAT
10	15569	AIR SHUTTER - LPG
11	15553	REAR LOG SUPPORT ASSEMBLY
12	R3623	PILOT ASSEMBLY - LPG
12	R3624	PILOT ASSEMBLY - NAT
13	15513	PILOT BRACKET
14	R7106	BURNER
15	R7221	FRONT LOG
16	R7220	REAR LOG
17	R7222	TOP LOG
18	15492	MOUNTING BRACKET - LOWER
19	15499	REAR COVER
20	CI328	WIRE CHANNEL
21	CI326	SWITCH BOX
22	R3436	ON/OFF/REMOTE SWITCH
23	15484	OUTLET BAFFLE
24	15493	MOUNTING BRACKET - UPPER
25	15478	INNER TOP
26	15483	INNER BODY
NS	R5668	IGNITOR WIRE
NS	R7295	WIRE ASSEMBLY
NS	CI253	MAGNET ASSEMBLY
NS	15568	TUBING - VALVE TO PILOT
NS	CI348	SWITCH BOX INSULATION



CIVF-25-20

Click Part # To View Price & Availability

PARTS LIST

Index No.	Part Number	Description
1	R3436	REMOTE/OFF/ON SWITCH
2	CI326	SWITCH BOX
3	CI199	WIRE CHANNEL ASSEMBLY
4	CI335	REAR COVER
5	R3643	REAR LOG
6	R3644	TOP LOG
7	R3642	FRONT LOG
8	CI023	BURNER BRACKET - RIGHT
9	CI258	AIR SHUTTER BODY
10	R3612	BURNER
11	R3623	PILOT ASSEMBLY-LPG W/THERMOPILE AND THERMO-COUPLE
11	R3624	PILOT ASSEMBLY-NAT W/THERMOPILE AND THERMO-COUPLE
12	CI180	PILOT TUBING
13	CI166	BURNER BRACKET - LEFT
14	CI338	LOG SUPPORT
15	CI351	LOG SUPPORT BAFFLE
16	CI207	INNER BOTTOM
17	CI027	INNER BOTTOM FACE ASSEMBLY
18	*CI009	LEG PAD - B (2 REQUIRED)
18	*CI008	LEG PAD - A (2 REQUIRED)
20	P8654	ORIFICE-LPG
20	P8640	ORIFICE-NAT
21	CI176	MANIFOLD ASSEMBLY
22	R3625	GAS VALVE - LPG
22	R3626	GAS VALVE - NAT
23	CI253	MAGNET ASSEMBLY (2 REQUIRED)
24	CI068	VALVE COVER ASSEMBLY
25	R2708	PIEZO IGNITOR
26	CI231	GLASS FRAME ASSEMBLY
27	R3628	GLASS-SIDE (2 REQUIRED)
28	R3627	GLASS FRONT
29	CI030	INNER BODY
30	CI192	REFLECTOR
31	CI189	INNER TOP FACE
32	CI187	INNER TOP
33	CI208	CATALYST HOLDER
34	R3629	CATALYST ELEMENT (2 REQUIRED)
35	CI211	OUTLET DUCT ASSEMBLY
36	CI217	OUTLET DUCT SHIELD
Not Shown	R2789	ELECTRODE WIRE
Not Shown	R3765	WIRE ASSEMBLY
Not Shown	* CI007	RETAINING TAB (4 REQUIRED)
Not Shown	* R3747	LEVELING BOLT (4 REQUIRED)
Not Shown	*CI006	WINDOW RETAINING TAB

* PART IS INCLUDED IN THE HARDWARE PACKAGE AND IS USED IN THE ASSEMBLY OF THE STOVE CASTING



CIVF-25C-1

Click Part # To View Price & Availability

PARTS LIST

Index No.	Part Number	Description
1	R3436	REMOTE/OFF/ON SWITCH
2	CI326	SWITCH BOX
3	CI328	WIRE CHANNEL
4	CI335	REAR COVER
5	R3643	REAR LOG
6	R3644	TOP LOG
7	R3642	FRONT LOG
8	CI023	BURNER BRACKET - RIGHT
9	CI258	AIR SHUTTER BODY
10	R3612	BURNER
11	R3623	PILOT ASSEMBLY-LPG
11	R3624	PILOT ASSEMBLY-NAT
12	CI180	PILOT TUBING
13	CI166	BURNER BRACKET - LEFT
14	CI338	LOG SUPPORT ASSEMBLY
15	CI351	LOG SUPPORT BAFFLE
16	CI207	INNER BOTTOM
17	R4053	DOOR LATCH (2 REQUIRED)
18	CI288	INNER BOTTOM FACE
19	CI272	GLASS FRAME GUIDE
20	* CI009	LEG PAD-B (2 REQ'D)
21	* CI008	LEG PAD-A (2 REQ'D)
22	P8654	ORIFICE-LPG
22	P8640	ORIFICE-NAT
23	CI176	MANIFOLD ASSEMBLY
24	R3625	GAS VALVE - LPG
24	R3626	GAS VALVE - NAT
25	CI253	MAGNET ASSEMBLY (2 REQUIRED)
26	CI068	VALVE COVER ASSEMBLY
27	R2708	PIEZO IGNITOR
28	CI389	GLASS FRAME ASSEMBLY
29	R4582	GLASS-SIDE (2 REQUIRED)
30	R4581	GLASS FRONT
31	CI280	INNER BODY
32	CI391	REFLECTOR
33	CI273	GLASS FRAME SUPPORT TOP
34	CI284	INNER TOP
35	CI209	CATALYST HOLDER
36	R3629A	CATALYST ELEMENT (2 REQUIRED)
37	CI399	OUTLET DUCT ASSEMBLY
38	CI217	OUTLET DUCT SHIELD
NOT SHOWN	CI348	SWITCH BOX INSULATION
NOT SHOWN	R5668	ELECTRODE WIRE
NOT SHOWN	R3765	WIRE ASSEMBLY
NOT SHOWN	* CI007	RETAINING TAB (4 REQUIRED)
NOT SHOWN	* R3747	LEVELING BOLT (4 REQUIRED)
NOT SHOWN	M166	MANIFOLD ORIFICE GASKET

* PART IS INCLUDED IN THE HARDWARE PACKAGE AND IS USED IN THE ASSEMBLY OF THE STOVE CASTING



CIVF-25C-2

Click Part # To View Price & Availability

PARTS LIST

Index No.	Part Number	Description
1	R3436	REMOTE/OFF/ON SWITCH
2	CI326	SWITCH BOX
3	CI328	WIRE CHANNEL
4	CI335	REAR COVER
5	R3863	REAR LOG
6	R3864	TOP LOG
7	R3862	FRONT LOG
8	CI023	BURNER BRACKET - RIGHT
9	CI258	AIR SHUTTER BODY
10	R5278	BURNER
11	R3623	PILOT ASSEMBLY-LPG
11	R3624	PILOT ASSEMBLY-NAT
12	CI180	PILOT TUBING
13	CI166	BURNER BRACKET - LEFT
14	CI338	LOG SUPPORT ASSEMBLY
15	CI351	LOG SUPPORT BAFFLE
16	CI207	INNER BOTTOM
17	R4053	DOOR LATCH (2 REQUIRED)
18	CI288	INNER BOTTOM FACE
19	CI272	GLASS FRAME GUIDE
20	* CI397	LEG PAD-B (2 REQ'D)
21	* CI393	LEG PAD-A (2 REQ'D)
22	P8654	ORIFICE-LPG
22	P8640	ORIFICE-NAT
23	CI176	MANIFOLD ASSEMBLY
24	R3625	GAS VALVE - LPG
24	R3626	GAS VALVE - NAT
25	CI253	MAGNET ASSEMBLY (2 REQUIRED)
26	CI068	VALVE COVER ASSEMBLY
27	R2708	PIEZO IGNITOR
28	CI389	GLASS FRAME ASSEMBLY
29	R4582	GLASS-SIDE (2 REQUIRED)
30	R4581	GLASS FRONT
31	CI280	INNER BODY
32	CI391	REFLECTOR
33	CI273	GLASS FRAME SUPPORT TOP
34	CI284	INNER TOP
35	CI209	CATALYST HOLDER
36	R3629A	CATALYST ELEMENT (2 REQUIRED)
37	CI399	OUTLET DUCT ASSEMBLY
38	CI217	OUTLET DUCT SHIELD
NOT SHOWN	CI348	SWITCH BOX INSULATION
NOT SHOWN	R5668	ELECTRODE WIRE
NOT SHOWN	R3765-A	WIRE ASSEMBLY
NOT SHOWN	* CI007	RETAINING TAB (4 REQUIRED)
NOT SHOWN	* R3747	LEVELING BOLT (4 REQUIRED)
NOT SHOWN	M166	MANIFOLD ORIFICE GASKET

* PART IS INCLUDED IN THE HARDWARE PACKAGE AND IS USED IN THE ASSEMBLY OF THE STOVE CASTING



CIVF-25C-3

Click Part # To View Price & Availability

PARTS LIST

Index No.	Part Number	Description
1	R3436	REMOTE/OFF/ON SWITCH
2	CI199	WIRE CHANNEL ASSEMBLY
3	CI198	REAR COVER
4	R3643	REAR LOG
5	R3644	TOP LOG
6	R3642	FRONT LOG
7	CI023	BURNER BRACKET - RIGHT
8	CI184	AIR SHUTTER BODY
9	CI238	FRONT LOG SUPPORT ASSEMBLY
10	R3612	BURNER
11	R3623	PILOT ASSEMBLY-LPG
11	R3624	PILOT ASSEMBLY-NAT
12	CI180	PILOT TUBING
13	CI166	BURNER BRACKET - LEFT
14	CI031	LOCATION WASHER (2 REQUIRED)
15	*CI008	LEG PAD-A (2 REQUIRED)
16	*CI009	LEG PAD-B (2 REQUIRED)
17	CI207	INNER BOTTOM
18	CI027	INNER BOTTOM FACE ASSEMBLY
19	R3625	GAS VALVE - LPG
19	R3626	GAS VALVE - NAT
20	P86145	ORIFICE-LPG
20	P8640	ORIFICE-NAT
21	CI176	MANIFOLD ASSEMBLY
22	CI253	MAGNET ASSEMBLY (2 REQUIRED)
23	CI068	VALVE COVER ASSEMBLY
24	R2708	PIEZO IGNITOR
25	CI231	GLASS FRAME ASSEMBLY
26	R3628	GLASS-SIDE (2 REQUIRED)
27	R3627	GLASS FRONT
28	CI190	REAR LOG SUPPORT ASSEMBLY
29	CI030	INNER BODY
30	CI192	REFLECTOR
31	CI189	INNER TOP FACE
32	CI187	INNER TOP
33	CI208	CATALYST HOLDER
34	R3629	CATALYST ELEMENT (2 REQUIRED)
35	CI211	OUTLET DUCT ASSEMBLY
36	CI217	OUTLET DUCT SHIELD
NS	R1226	THERMOSTAT
NS	R2789	ELECTRODE WIRE
NS	R3765	WIRE ASSEMBLY
NS	* CI007	RETAINING TAB (4 REQUIRED)
NS	* R3747	LEVELING BOLT (4 REQUIRED)

CIVF-25C-3 with Screw on Door



CIVF-25C-3 with Screw on Door

Click Part # To View Price & Availability

PARTS LIST

Index No.	Part Number	Description
1	R3436	REMOTE/OFF/ON SWITCH
2	CI162	WIRE CHANNEL ASSEMBLY
3	CI161	REAR COVER
4	R3641	VENT ELBOW
5	M160	GASKET - VENT ELBOW
6	CI138	AIR DROP ASSEMBLY
7	DVF102	RELIEF DOOR BRACKET (4 REQUIRED)
8	CI115	RELIEF DOOR ASSEMBLY - LEFT
9	CI118	RELIEF DOOR ASSEMBLY - RIGHT
10	M96	FLUE OUTLET GASKET
11	CI124	FLUE OUTLET ASSEMBLY
12	CI088	SIDE SHIELD (2 REQUIRED)
13	CI106	INNER TOP ASSEMBLY
14	CI121	INNER TOP FACE ASSEMBLY
15	CI148	INTERNAL BAFFLE
16	CI104	INNER BODY ASSEMBLY
17	CI136	REAR LOG SUPPORT ASSEMBLY
18	CI156	GLASS W/GASKET - SIDE (2 REQUIRED)
19	CI158	GLASS W/GASKET - FRONT
20	CI149	GLASS FRAME
21	R2708	PIEZO IGNITOR
22	CI143	VALVE COVER ASSEMBLY
23	CI253	MAGNET ASSEMBLY (2 REQUIRED)
24	* CI008	LEG PAD-A (2 REQ'D)
25	* CI009	LEG PAD-B (2 REQ'D)
26	R3318	GAS VALVE - NAT
26	R3319	GAS VALVE - LPG
27	R1259	3/8 NPT X 3/8 NPT STREET ELBOW
28	CI016	MANIFOLD ASSEMBLY
29	P8638	ORIFICE-NAT
29	P8653	ORIFICE-LPG
30	CI101	INNER BOTTOM FACE ASSEMBLY
31	CI145	DELAYED IGNITION RESET SWITCH ASSEMBLY
32	CI031	LOCATION WASHER (2 REQUIRED)
33	CI338	INNER BOTTOM ASSEMBLY
34	M148	GASKET - MANIFOLD
35	M157	GASKET - SEAL BRACKET

PARTS LIST

Index No.	Part Number	Description
36	DVF039	SEAL BRACKET
37	CI024	AIR SHUTTER BODY
38	CI023	BURNER BRACKET - RIGHT
39	R3758	ADJUSTING SCREW
40	CI025	AIR SHUTTER TOP
41	R3612	BURNER
42	CI022	BURNER BRACKET - LEFT
43	R3473	THERMOCOUPLE
44	CI018	PILOT TUBING
45	R3475	THERMOPILE
46	R3465	PILOT ASSEMBLY-NAT WITH ELECTRODE
46	R3466	PILOT ASSEMBLY-LPG WITH ELECTRODE
47	CI064	FRONT LOG SUPPORT ASSEMBLY
48	R3642	FRONT LOG
49	R3644	TOP LOG
50	R3643	REAR LOG
Not Shown	R1226	THERMOSTAT
Not Shown	CI155	CABLE ASSEMBLY (DELAYED IGNITON RESET SWITCH)
Not Shown	R3766	WIRE ASSEMBLY (DELAYED IGNITON RESET SWITCH)
Not Shown	R3765	WIRE ASSEMBLY
Not Shown	* CI006	WINDOW RETAINING TAB
Not Shown	* R3747	LEVELING BOLT (4 REQUIRED)
Not Shown	R3406	PILOT ASSEMBLY NAT WITH THERMOPILE AND THERMOCOUPLE
Not Shown	R3407	PILOT ASSEMBLY LPG WITH THERMOPILE AND THERMOCOUPLE
Not Shown	CI235	RESTRICTOR PLATE WITH GASKET, USED IN A COMPLETELY VERTICAL RISE BETWEEN 10' AND 25'

* PART IS INCLUDED IN THE HARDWARE PACKAGE AND IS USED IN THE ASSEMBLY OF THE STOVE CASTING

Conversion Kit

To LP	To Natural
CI089	CI090

CIDV-30-1

Click Part # To View Price & Availability



CIDV-30-1

PARTS LIST

Index No.	Part Number	Description
1	R3436	REMOTE/OFF/ON SWITCH
2	CI086	CHANNEL DIVIDER
3	CI164	WIRE CHANNEL
4	CI161	REAR COVER
5	R3641	VENT ELBOW
6	M160	GASKET - VENT ELBOW
7	CI138	AIR DROP ASSEMBLY
8	CI263	TOP SHIELD
9	CI260	RELIEF DOOR BRACKET (4 REQ'D)
10	CI115	RELIEF DOOR ASSEMBLY - LEFT
11	CI118	RELIEF DOOR ASSEMBLY - RIGHT
12	M96	FLUE OUTLET GASKET (3 REQ'D)
13	CI124	FLUE OUTLET ASSEMBLY
14	CI267	INNER TOP ASSEMBLY
15	CI121	INNER TOP FACE ASSEMBLY
16	CI324	INTERNAL BAFFLE
17	CI264	SIDE SHIELD - LEFT
18	CI104	INNER BODY ASSEMBLY
19	CI265	SIDE SHIELD - RIGHT
20	CI061	REAR LOG ASSEMBLY
21	CI156	GLASS ASSEMBLY - SIDE (2 REQ'D)
22	CI158	GLASS ASSEMBLY - FRONT
23	CI150	GLASS FRAME ASSEMBLY
24	R2708	PIEZO IGNITOR
25	CI143	VALVE COVER ASSEMBLY
26	CI253	MAGNET ASSEMBLY (2 REQ'D)
27	R3318	GAS VALVE - NAT
27	R3319	GAS VALVE - LPG
28	R1259	3/8 NPT X 3/8 NPT STREET ELBOW
29	CI016	MANIFOLD ASSEMBLY
30	P8638	BURNER ORIFICE-NAT
30	P8654	BURNER ORIFICE-LPG
31	* CI008	LEG PAD-A (2 REQ'D)
32	* CI009	LEG PAD-B (2 REQ'D)

PARTS LIST

Index No.	Part Number	Description
33	CI101	INNER BOTTOM FACE ASSEMBLY
34	CI145	DELAYED IGNITION RESET SWITCH ASSEMBLY
35	CI035	LOCATION WASHER (2 REQ'D)
36	CI099	INNER BOTTOM ASSEMBLY
37	M148	GASKET - MANIFOLD
38	M157	GASKET - SEAL BRACKET
39	DVF039	SEAL BRACKET
40	CI257	AIR SHUTTER BODY
41	CI023	BURNER BRACKET - RIGHT
42	R3758	ADJUSTING SCREW
43	CI025	AIR SHUTTER TOP
44	R3612	BURNER
45	CI022	BURNER BRACKET - LEFT
46	R3473	THERMOCOUPLE
47	CI018	PILOT TUBING
48	R3475	THERMOPILE
49	R3465	PILOT ASSEMBLY-NAT
49	R3466	PILOT ASSEMBLY-LPG
50	CI338	LOG SUPPORT SUPPORT ASSEMBLY
51	R3642	FRONT LOG
52	R3644	TOP LOG
53	R3643	REAR LOG
NOT SHOWN	CI155	CABLE ASSEMBLY (DELAYED IGNITION RESET SWITCH)
NOT SHOWN	R3766	WIRE ASSEMBLY (DELAYED IGNITION RESET SWITCH)
NOT SHOWN	R3765	WIRE ASSEMBLY
NOT SHOWN	R4505	TUBE OF FURNACE CEMENT
NOT SHOWN	* CI007	RETAINING TAB (4 REQ'D)
NOT SHOWN	* R3747	LEVELING BOLT (4 REQ'D)
NOT SHOWN	CI235	RESTRICTOR PLATE USED IN A VERTICAL RISE BETWEEN 15' AND 25'

Conversion Kit

To LP	To Natural
CI089	CI090

CIDV-30-2

Click Part # To View Price & Availability


CIDV-30-2
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53

CIDV-30-2

PARTS LIST

Index No.	Part Number	Description
1	R3436	REMOTE/OFF/ON SWITCH
2	CI329	WIRE CHANNEL
3	CI331	CHANNEL DIVIDER
4	CI330	CASING SUPPORT
5	CI307	REAR COVER
6	R4600	VENT ELBOW
7	M160	GASKET - VENT ELBOW
8	CI332	AIR DROP ASSEMBLY
9	CI263	TOP SHIELD
10	CI260	RELIEF DOOR BRACKET (4 REQ'D)
11	CI115	RELIEF DOOR ASSEMBLY - LEFT
12	CI118	RELIEF DOOR ASSEMBLY - RIGHT
13	CI341	INNER TOP ASSEMBLY
14	CI121	INNER TOP FACE ASSEMBLY
15	M96	FLUE OUTLET GASKET (3 REQ'D)
16	CI274	SIDE SHIELD (2 REQ'D)
17	CI337	INNER BODY ASSEMBLY
18	CI324	INTERNAL BAFFLE
19	CI156	GLASS ASSEMBLY - SIDE (2 REQ'D)
20	CI158	GLASS ASSEMBLY - FRONT
21	CI150	GLASS FRAME ASSEMBLY
22	R2708	PIEZO IGNITOR
23	CI143	VALVE COVER ASSEMBLY
24	CI253	MAGNET ASSEMBLY (2 REQ'D)
25	R3318	GAS VALVE - NAT
25	R3319	GAS VALVE - LPG
26	R1259	3/8 NPT X 3/8 NPT STREET ELBOW
27	CI016	MANIFOLD ASSEMBLY
28	P8638	BURNER ORIFICE-NAT
28	P8654	BURNER ORIFICE-LPG
29	* CI008	LEG PAD-A (2 REQ'D)
30	* CI009	LEG PAD-B (2 REQ'D)
31	CI101	INNER BOTTOM FACE ASSEMBLY
32	CI145	DELAYED IGNITION RESET SWITCH ASSEMBLY
33	CI099	INNER BOTTOM ASSEMBLY

PARTS LIST

Index No.	Part Number	Description
34	M148	GASKET - MANIFOLD
35	M157	GASKET - SEAL BRACKET
36	DVF039	SEAL BRACKET
37	CI257	AIR SHUTTER BODY
38	CI023	BURNER BRACKET - RIGHT
39	R3758	ADJUSTING SCREW
40	CI025	AIR SHUTTER TOP
41	R3612	BURNER
42	CI022	BURNER BRACKET - LEFT
43	R3473	THERMOCOUPLE
44	CI018	PILOT TUBING
45	R3475	THERMOPILE
46	R3465	PILOT ASSEMBLY-NAT
46	R3466	PILOT ASSEMBLY-LPG
47	CI338	LOG SUPPORT
48	R3642	FRONT LOG
49	R3644	TOP LOG
50	R3643	REAR LOG
NOT SHOWN	R3406	PILOT ASSEMBLY - NAT. WITH THERMOPILE & THERMOCOUPLE
NOT SHOWN	R3407	PILOT ASSEMBLY - LPG WITH THERMOPILE & THERMOCOUPLE
NOT SHOWN	CI155	CABLE ASSEMBLY (DELAYED IGNITION RESET SWITCH)
NOT SHOWN	R3766	WIRE ASSEMBLY (DELAYED IGNITION RESET SWITCH)
NOT SHOWN	R3765	WIRE ASSEMBLY
NOT SHOWN	R4505	TUBE OF FURNACE CEMENT
NOT SHOWN	* CI007	RETAINING TAB (4 REQ'D)
NOT SHOWN	* R3747	LEVELING BOLT (4 REQ'D)
NOT SHOWN	CI235	RESTRICTOR PLATE USED IN A VERTICAL RISE BETWEEN 15' AND 25'

	Conversion Kit	
	To LP	To Natural
	CI089	CI090

CIDV-30-5

Click Part # To View Price & Availability



CIDV-30-5

PARTS LIST

Index No.	Part Number	Description
1	R3436	REMOTE/OFF/ON SWITCH
2	CI329	WIRE CHANNEL
3	CI331	CHANNEL DIVIDER
4	CI330	CASING SUPPORT
5	CI307	REAR COVER
6	R4600	VENT ELBOW
7	M160	GASKET - VENT ELBOW
8	CI332	AIR DROP ASSEMBLY
9	CI364	RELIEF DOOR ASSEMBLY
10	CI375	RELIEF DOOR BRACKET (2 REQUIRED)
11	CI363	INNER TOP ASSEMBLY
12	CI273	GLASS FRAME SUPPORT TOP
13	M163	FLUE CONNECTOR TUBE GASKET (3 REQUIRED)
14	CI274	SIDE SHIELD (2 REQUIRED)
15	CI275	INNER BODY
16	CI324	INTERNAL BAFFLE
17	CI355	GLASS ASSEMBLY - SIDE (2 REQUIRED)
18	CI356	GLASS ASSEMBLY - FRONT
19	CI354	GLASS FRAME ASSEMBLY
20	R2708	PIEZO IGNITOR
21	CI143	VALVE COVER ASSEMBLY
22	CI253	MAGNET ASSEMBLY (2 REQUIRED)
23	R3318	GAS VALVE - NAT
23	R3319	GAS VALVE - LPG
24	R1259	3/8 NPT X 3/8 NPT STREET ELBOW
25	CI016	MANIFOLD ASSEMBLY
26	P8638	ORIFICE-NAT
26	P8654	ORIFICE-LPG
27	* CI008	LEG PAD-A (2 REQUIRED)
28	* CI009	LEG PAD-B (2 REQUIRED)
29	CI272	GLASS FRAME GUIDE
30	CI362	INNER BOTTOM FACE ASSEMBLY
31	CI145	DELAYED IGNITION RESET SWITCH ASSEMBLY
32	R4053	DOOR LATCH (2 REQUIRED)
33	CI361	INNER BOTTOM ASSEMBLY

PARTS LIST

Index No.	Part Number	Description
34	M164	GASKET - MANIFOLD
35	M157	GASKET - SEAL BRACKET
36	DVF039	SEAL BRACKET
37	CI257	AIR SHUTTER BODY
38	CI023	BURNER BRACKET - RIGHT
39	R3758	ADJUSTING SCREW
40	CI025	AIR SHUTTER TOP
41	R3612	BURNER
42	CI022	BURNER BRACKET - LEFT
43	R3473	THERMOCOUPLE
44	CI018	PILOT TUBING
45	R3475	THERMOPILE
46	R3465	PILOT ASSEMBLY-NAT
46	R3466	PILOT ASSEMBLY-LPG
47	CI338	LOG SUPPORT ASSEMBLY
48	R3642	FRONT LOG
49	R3644	TOP LOG
50	R3643	REAR LOG
NOT SHOWN	R3406	PILOT ASSEMBLY - NAT. WITH THERMOPILE THERMOCOUPLE
NOT SHOWN	R3407	PILOT ASSEMBLY - LPG WITH THERMOPILE THERMOCOUPLE
NOT SHOWN	CI350	CABLE ASSEMBLY (DELAYED IGNITION RESET SWITCH)
NOT SHOWN	R3766	WIRE ASSEMBLY (DELAYED IGNITION RESET SWITCH)
NOT SHOWN	R3765	WIRE ASSEMBLY
NOT SHOWN	R4505	TUBE OF FURNACE CEMENT
NOT SHOWN	* CI007	RETAINING TAB (4 REQUIRED)
NOT SHOWN	* R3747	LEVELING BOLT (4 REQUIRED
NOT SHOWN	CI235	RESTRICTOR PLATE USED IN A VETICAL RISE BETWEEN 15' AND 25'

Conversion Kit

To LP	To Natural
CI089	CI090

Click Part # To View
Price & Availability


CIDV-30-6
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50

CIDV-30-6

PARTS LIST

Index No.	Part Number	Description
1	R3436	REMOTE/OFF/ON SWITCH
2	CI329	WIRE CHANNEL
3	CI331	CHANNEL DIVIDER
4	CI330	CASING SUPPORT
5	CI307	REAR COVER
6	M160	GASKET - VENT ELBOW
7	CI332	AIR DROP ASSEMBLY
8	CI364	RELIEF DOOR ASSEMBLY
9	CI375	RELIEF DOOR BRACKET (2 REQUIRED)
10	CI363	INNER TOP ASSEMBLY
11	CI273	GLASS FRAME SUPPORT TOP
12	M163	FLUE CONNECTOR TUBE GASKET (3 REQUIRED)
13	CI274	SIDE SHIELD (2 REQUIRED)
14	CI275	INNER BODY
15	CI324	INTERNAL BAFFLE
16	CI355	GLASS ASSEMBLY - SIDE (2 REQUIRED)
17	CI356	GLASS ASSEMBLY - FRONT
18	CI354	GLASS FRAME ASSEMBLY
19	R2708	PIEZO IGNITOR
20	CI143	VALVE COVER ASSEMBLY
21	CI253	MAGNET ASSEMBLY (2 REQUIRED)
22	R3318	GAS VALVE - NAT
22	R3319	GAS VALVE - LPG
23	R1259	3/8 NPT X 3/8 NPT STREET ELBOW
24	CI016	MANIFOLD ASSEMBLY
25	P8638	ORIFICE-NAT
25	P8654	ORIFICE-LPG
26	* CI008	LEG PAD-A (2 REQUIRED)
27	* CI009	LEG PAD-B (2 REQUIRED)
28	CI272	GLASS FRAME GUIDE
29	CI362	INNER BOTTOM FACE ASSEMBLY
30	CI145	DELAYED IGNITION RESET SWITCH ASSEMBLY
31	R4053	DOOR LATCH (2 REQUIRED)
32	CI361	INNER BOTTOM ASSEMBLY
33	M164	GASKET - MANIFOLD
34	M157	GASKET - SEAL BRACKET

PARTS LIST

Index No.	Part Number	Description
35	DVF039	SEAL BRACKET
36	CI257	AIR SHUTTER BODY
37	CI023	BURNER BRACKET - RIGHT
38	R3758	ADJUSTING SCREW
39	CI025	AIR SHUTTER TOP
40	R5278	BURNER
41	CI022	BURNER BRACKET - LEFT
42	R3473	THERMOCOUPLE
43	CI018	PILOT TUBING
44	R5285	THERMOPILE
45	R3465	PILOT WITH ORIFICE (NAT ONLY)
45	R3466	PILOT WITH ORIFICE (LPG ONLY)
46	CI338	LOG SUPPORT ASSEMBLY
47	R3642	FRONT LOG
48	R3644	TOP LOG
49	R3643	REAR LOG
NOT SHOWN	R5143	PILOT ASSEMBLY - NAT. WITH THERMOPILE THERMOCOUPLE
NOT SHOWN	R5144	PILOT ASSEMBLY - LPG WITH THERMOPILE THERMOCOUPLE
NOT SHOWN	CI350	CABLE ASSEMBLY (DELAYED IGNITION RESET SWITCH)
NOT SHOWN	R3766	WIRE ASSEMBLY (DELAYED IGNITION RESET SWITCH)
NOT SHOWN	R3765-A	WIRE ASSEMBLY
NOT SHOWN	R4505	TUBE OF FURNACE CEMENT
NOT SHOWN	* CI007	RETAINING TAB (4 REQUIRED)
NOT SHOWN	* R3747	LEVELING BOLT (4 REQUIRED
NOT SHOWN	CI235	RESTRICTOR PLATE USED IN A VERTICAL RISE BETWEEN 15' AND 25'

* PART IS INCLUDED IN THE HARDWARE PACKAGE AND IS USED IN THE ASSEMBLY OF THE STOVE CASTING

Conversion Kit

To LP	To Natural
CI089	CI090

CIDV-30-7

Click Part # To View Price & Availability


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49

CIDV-30-7

PARTS LIST

Index No.	Part Number	Description
1	R3436	REMOTE/OFF/ON SWITCH
2	CI329	WIRE CHANNEL
3	CI331	CHANNEL DIVIDER
4	CI330	CASING SUPPORT
5	CI307	REAR COVER
6	M160	GASKET - VENT ELBOW
7	CI332	AIR DROP ASSEMBLY
8	CI364	RELIEF DOOR ASSEMBLY
9	CI375	RELIEF DOOR BRACKET (2 REQUIRED)
10	CI363	INNER TOP ASSEMBLY
11	CI273	GLASS FRAME SUPPORT TOP
12	M163	FLUE CONNECTOR TUBE GASKET (3 REQUIRED)
13	CI274	SIDE SHIELD (2 REQUIRED)
14	CI275	INNER BODY
15	CI324	INTERNAL BAFFLE
16	CI355	GLASS ASSEMBLY - SIDE (2 REQUIRED)
17	CI356	GLASS ASSEMBLY - FRONT
18	CI354	GLASS FRAME ASSEMBLY
19	R2708	PIEZO IGNITOR
20	CI143	VALVE COVER ASSEMBLY
21	CI253	MAGNET ASSEMBLY (2 REQUIRED)
22	R3318	GAS VALVE - NAT
22	R3319	GAS VALVE - LPG
23	R1259	3/8 NPT X 3/8 NPT STREET ELBOW
24	CI016	MANIFOLD ASSEMBLY
25	P8638	ORIFICE-NAT
25	P8654	ORIFICE-LPG
26	* CI393	LEG PAD-A (2 REQUIRED)
27	* CI397	LEG PAD-B (2 REQUIRED)
28	CI272	GLASS FRAME GUIDE
29	CI362	INNER BOTTOM FACE ASSEMBLY
30	CI145	DELAYED IGNITION RESET SWITCH ASSEMBLY
31	R4053	DOOR LATCH (2 REQUIRED)
32	CI361	INNER BOTTOM ASSEMBLY
33	M164	GASKET - MANIFOLD

PARTS LIST

Index No.	Part Number	Description
34	M157	GASKET - SEAL BRACKET
35	DVF039	SEAL BRACKET
36	CI257	AIR SHUTTER BODY
37	CI023	BURNER BRACKET - RIGHT
38	R3758	ADJUSTING SCREW
39	CI025	AIR SHUTTER TOP
40	R5278	BURNER
41	CI022	BURNER BRACKET - LEFT
42	R3473	THERMOCOUPLE
43	CI018	PILOT TUBING
44	R5285	THERMOPILE
45	R3465	PILOT WITH ORIFICE (NAT ONLY)
45	R3466	PILOT WITH ORIFICE (LPG ONLY)
46	CI338	LOG SUPPORT ASSEMBLY
47	R3862	FRONT LOG
48	R3864	TOP LOG
49	R3863	REAR LOG
NOT SHOWN	R5143	PILOT ASSEMBLY - NAT. WITH THERMOPILE THERMOCOUPLE
NOT SHOWN	R5144	PILOT ASSEMBLY - LPG WITH THERMOPILE THERMOCOUPLE
NOT SHOWN	CI350	CABLE ASSEMBLY (DELAYED IGNITION RESET SWITCH)
NOT SHOWN	R3766	WIRE ASSEMBLY (DELAYED IGNITION RESET SWITCH)
NOT SHOWN	R3765-A	WIRE ASSEMBLY
NOT SHOWN	R4505	TUBE OF FURNACE CEMENT
NOT SHOWN	* CI007	RETAINING TAB (4 REQUIRED)
NOT SHOWN	* R3747	LEVELING BOLT (4 REQUIRED
NOT SHOWN	CI235	RESTRICTOR PLATE USED IN A VERTICAL RISE BETWEEN 15' AND 25'

* PART IS INCLUDED IN THE HARDWARE PACKAGE AND IS USED IN THE ASSEMBLY OF THE STOVE CASTING

Conversion Kit

To LP	To Natural
CI089	CI090

CIDV-30-8

Click Part # To View Price & Availability


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49

CIDV-30-8

PARTS LIST

Index No.	Part Number	Description
1	R2708	PIEZO IGNITOR
2	15516	VALVE COVER ASSEMBLY
3	15623	DELAYED IGNITION RESET SWITCH ASSEMBLY
4	R4053	DOOR LATCH
5	15490	VALVE BRACKET
6	R3318	GAS VALVE - NAT
6	R3319	GAS VALVE - LPG
7	R2423	BRASS MALE CONNECTOR
8	15556	TUBING - VALVE TO BURNER
9	M157	SEAL BRACKET GASKET
10	DVF039	SEAL BRACKET
11	M174	GAS LINE GASKET
12	11269	GAS LINE BRACKET
13	15611	INNER BOTTOM ASSEMBLY
14	P253	ORIFICE FITTING
15	P243	ORIFICE - NAT
15	P185	ORIFICE - LPG
16	R3357	SPRING
17	15569	AIR SHUTTER - NAT
17	15558	AIR SHUTTER - LPG
18	R7106	BURNER
19	15512	PILOT BRACKET
20	R5143	PILOT ASSEMBLY - NAT
20	R5144	PILOT ASSEMBLY - LPG
21	15553	REAR LOG SUPPORT ASSEMBLY

PARTS LIST

Index No.	Part Number	Description
22	15482	INNER BODY
23	15503	FLUE RESTRICTOR
24	15515	SIDE SHIELD
25	15625	INNER TOP
26	15511	MOUNTING BRACKET UPPER - LEFT
27	15510	MOUNTING BRACKET UPPER - RIGHT
28	CI375	RELEIF DOOR BRACKET (2 REQ'D)
29	CI364	RELEIF DOOR ASSEMBLY
30	M163	FLUE CONNECTOR TUBE GASKETS
31	15612	AIR DROP ASSEMBLY
32	M160	VENT ELBOW GASKET
33	R7221	FRONT LOG
34	R7220	REAR LOG
35	R7222	TOP LOG
36	15609	GLASS ASSEMBLY
37	15502	GLASS FRAME
38	R3436	ON/OFF/REMOTE SWITCH
39	CI331	CHANNEL DIVIDER
40	CI329	WIRE CHANNEL
41	15501	CASING SUPPORT
42	15497	REAR COVER
NS	R7294	WIRE ASSEMBLY
NS	CI253	MAGNET ASSEMBLY
NS	15610	TUBING - VALVE TO PILOT
NS	CI350	CABLE ASSEMBLY

Click Part # To View
Price & Availability


32
31
30
29
28
27
26
25
35
34
33
24
24
23
22
21
36
37
38
39
40
41
42
20
17
16
15
14
19
18
13
11
9
12
10
4
4
5
8
3
7
6
2
1

CIDV-30-20

PARTS LIST

Index No.	Part Number	Description
1	R3436	REMOTE/OFF/ON SWITCH
2	CI199	WIRE CHANNEL WELDED ASSEMBLY
3	CI081	REAR COVER WELDED ASSEMBLY
4	CI055	DIVERTER OUTLET ASSEMBLY
5	CI047	DIVERTER BODY ASSEMBLY
6	CI043	DIVERTER BACK ASSEMBLY
7	CI032	INNER TOP ASSEMBLY
8	CI040	INNER TOP FACE ASSEMBLY
9	CI192	REFLECTOR
10	CI030	INNER BODY
11	CI088	SIDE SHIELD (2 REQUIRED)
12	CI061	REAR LOG SUPPORT ASSEMBLY
13	R3628	GLASS-SIDE (2 REQUIRED)
14	R3627	GLASS-FRONT
15	CI073	GLASS FRAME W/GASKET
16	R2708	PIEZO IGNITOR
17	CI143	VALVE COVER ASSEMBLY
18	CI253	MAGNET ASSEMBLY (2 REQUIRED)
19	R3632	GAS VALVE-LPG
19	R3633	GAS VALVE-NAT
20	R1259	3/8 NPT X 3/8 NPT STREET ELBOW
21	CI016	MANIFOLD ASSEMBLY
22	P86155	MAIN BURNER ORIFICE-LPG
22	P8638	MAIN BURNER ORIFICE-NAT
23	* CI008	LEG PAD-A (2 REQUIRED)
24	* CI009	LEG PAD-B (2 REQUIRED)
25	CI027	INNER BOTTOM FACE ASSEMBLY
26	CI031	LOCATION WASHER (2 REQUIRED)
27	M148	MANIFOLD GASKET

PARTS LIST

Index No.	Part Number	Description
28	CI020	INNER BOTTOM ASSEMBLY
29	CI023	BURNER BRACKET-RIGHT
30	CI024	AIR SHUTTER BODY
31	R3612	BURNER
32	CI022	BURNER BRACKET-LEFT
33	R3475	THERMOPILE 18"
34	CI018	PILOT TUBING
35	R3630	PILOT ASSEMBLY COMPLETE - LPG (INCLUDES ITEM 33)
35	R3631	PILOT ASSEMBLY COMPLETE - NAT (INCLUDES ITEM 33)
36	CI338	FRONT LOG SUPPORT ASSEMBLY
37	CI025	AIR SHUTTER TOP
38	R3758	AIR SHUTTER ADJUSTING SCREW
39	R3642	FRONT LOG
40	R3644	TOP LOG
41	R3643	REAR LOG
42	R3634	ECO LIMIT SWITCH
43	R3768	ECO WIRE ASSEMBLY
Not Shown	R1266	THERMOSTAT
Not Shown	* R3747	LEVELING BOLT (4 REQUIRED)
Not Shown	* CI007	RETAINING TAB (4 REQUIRED)
Not Shown	R3765	WIRE ASSEMBLY
Not Shown	*CI006	WINDOW RETAINING TAB

* PART IS INCLUDED IN THE HARDWARE PACKAGE AND IS USED IN THE ASSEMBLY OF THE STOVE CASTING

Conversion Kit

To LP	To Natural
CI089	CI090

CIBV-30-1

Click Part # To View Price & Availability


CIBV-30-1
1
2
3
4
5
6
7
8
9
10
11
12a
12b
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42

CIBV-30-1

PARTS LIST

Index No.	Part Number	Description
1	R3436	REMOTE/OFF/ON SWITCH
2	CI326	SWITCH BOX
3	CI328	WIRE CHANNEL
4	CI336	REAR COVER WELDED ASSEMBLY
5	CI055	DIVERTER OUTLET ASSEMBLY
6	CI370	DIVERTER BODY ASSEMBLY
7	CI043	DIVERTER BACK ASSEMBLY
8	CI369	INNER TOP ASSEMBLY
9	CI273	GLASS FRAME SUPPORT TOP
10	CI391	REFLECTOR
11	CI280	INNER BODY
12	CI274	SIDE SHIELD (2 REQUIRED)
13	R4582	GLASS-SIDE (2 REQUIRED)
14	R4581	GLASS-FRONT
15	CI269	GLASS FRAME ASSEMBLY
16	R2708	PIEZO IGNITOR
17	CI143	VALVE COVER ASSEMBLY
18	CI253	MAGNET ASSEMBLY (2 REQUIRED)
19	R3632	GAS VALVE-LPG
19	R3633	GAS VALVE-NAT
20	R1259	3/8 NPT X 3/8 NPT STREET ELBOW
21	CI016	MANIFOLD ASSEMBLY
22	P8653	MAIN BURNER ORIFICE-LPG
22	P8638	MAIN BURNER ORIFICE-NAT
23	* CI008	LEG PAD-A (2 REQUIRED)
24	* CI009	LEG PAD-B (2 REQUIRED)
25	CI272	GLASS FRAME GUIDE
26	CI288	INNER BOTTOM FACE
27	R4053	DOOR LATCH (2 REQUIRED)

PARTS LIST

Index No.	Part Number	Description
28	M164	MANIFOLD GASKET
29	CI020	INNER BOTTOM ASSEMBLY
30	CI023	BURNER BRACKET-RIGHT
31	CI257	AIR SHUTTER BODY
32	R3612	BURNER
33	CI022	BURNER BRACKET-LEFT
34	R3475	THERMOPILE 18"
35	CI018	PILOT TUBING
36	R3630	PILOT ASSEMBLY COMPLETE - LPG (INCLUDES ITEM 32)
36	R3631	PILOT ASSEMBLY COMPLETE - NAT (INCLUDES ITEM 32)
37	CI338	LOG SUPPORT ASSEMBLY
38	CI025	AIR SHUTTER TOP
39	R3758	AIR SHUTTER ADJUSTING SCREW
40	R3642	FRONT LOG
41	R3644	TOP LOG
42	R3643	REAR LOG
43	R3981	ECO LIMIT SWITCH
44	R3768	ECO WIRE ASSEMBLY
NOT SHOWN	CI348	SWITCH BOX INSULATION
NOT SHOWN	* R3747	LEVELING BOLT (4 REQUIRED)
NOT SHOWN	* CI007	RETAINING TAB (4 REQUIRED)
NOT SHOWN	R3765	WIRE ASSEMBLY

* PART IS INCLUDED IN THE HARDWARE PACKAGE AND IS USED IN THE ASSEMBLY OF THE STOVE CASTING

CIBV-30-2

Conversion Kit

To LP	To Natural
CI089	CI090

Click Part # To View Price & Availability


CIBV-30-2
1
2
3
4
5
6
7
8
9
10
11
12
12
13
13
14
15
16
17
18
19
20
21
22
23
23
24
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44

CIBV-30-2

PARTS LIST

Index No.	Part Number	Description
1	R3436	REMOTE/OFF/ON SWITCH
2	CI326	SWITCH BOX
3	CI328	WIRE CHANNEL
4	CI336	REAR COVER WELDED ASSEMBLY
5	11228	DIVERTER OUTLET ASSEMBLY
6	CI370	DIVERTER BODY ASSEMBLY
7	CI043	DIVERTER BACK ASSEMBLY
8	CI369	INNER TOP ASSEMBLY
9	CI273	GLASS FRAME SUPPORT TOP
10	CI391	REFLECTOR
11	CI280	INNER BODY
12	CI274	SIDE SHIELD (2 REQUIRED)
13	R4582	GLASS-SIDE (2 REQUIRED)
14	R4581	GLASS-FRONT
15	CI269	GLASS FRAME ASSEMBLY
16	R2708	PIEZO IGNITOR
17	CI143	VALVE COVER ASSEMBLY
18	CI253	MAGNET ASSEMBLY (2 REQUIRED)
19	R3632	GAS VALVE-LPG
19	R3633	GAS VALVE-NAT
20	R1259	3/8 NPT X 3/8 NPT STREET ELBOW
21	CI016	MANIFOLD ASSEMBLY
22	P8653	MAIN BURNER ORIFICE-LPG
22	P8638	MAIN BURNER ORIFICE-NAT
23	* CI008	LEG PAD-A (2 REQUIRED)
24	* CI009	LEG PAD-B (2 REQUIRED)
25	CI272	GLASS FRAME GUIDE
26	CI288	INNER BOTTOM FACE
27	R4053	DOOR LATCH (2 REQUIRED)
28	M164	MANIFOLD GASKET
29	CI020	INNER BOTTOM ASSEMBLY
30	CI023	BURNER BRACKET-RIGHT
31	CI257	AIR SHUTTER BODY

PARTS LIST

Index No.	Part Number	Description
32	R5278	BURNER
33	CI022	BURNER BRACKET-LEFT
34	R3475	THERMOPILE 18"
35	CI018	PILOT TUBING
36	R3630	PILOT ASSEMBLY COMPLETE - LPG (INCLUDES ITEM 32)
36	R3631	PILOT ASSEMBLY COMPLETE - NAT (INCLUDES ITEM 32)
37	CI338	LOG SUPPORT ASSEMBLY
38	CI025	AIR SHUTTER TOP
39	R3758	AIR SHUTTER ADJUSTING SCREW
40	R3862	FRONT LOG
41	R3864	TOP LOG
42	R3863	REAR LOG
43	R3981	ECO LIMIT SWITCH
44	R3768	ECO WIRE ASSEMBLY
NOT SHOWN	CI348	SWITCH BOX INSULATION
NOT SHOWN	* R3747	LEVELING BOLT (4 REQUIRED)
NOT SHOWN	* CI007	RETAINING TAB (4 REQUIRED)
NOT SHOWN	R3765-A	WIRE ASSEMBLY

* PART IS INCLUDED IN THE HARDWARE PACKAGE AND IS USED IN THE ASSEMBLY OF THE STOVE CASTING

Conversion Kit

To LP	To Natural
CI089	CI090

CIBV-30-3

Click Part # To View Price & Availability


1
2
3
4
5
6
7
8
9
10
11
12
12
13
13
14
15
16
17
18
19
20
21
22
23
23
24
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44

CIBV-30-3

PARTS LIST

Index No.	Part Number	Description
1	R2708	PIEZO IGNITOR
2	15516	VALVE COVER ASSEMBLY
3	R4053	LATCH
4	15490	VALVE BRACKET
5	R3633	GAS VALVE - NAT
5	R3632	GAS VALVE - LPG
6	R2423	BRASS MALE CONNECTOR
7	15556	TUBING - VALVE TO BURNER
8	P253	ORIFICE FITTING
9	P185	ORIFICE - LPG
9	P243	ORIFICE - NAT
10	R3357	SPRING
11	15569	AIR SHUTTER - NAT
11	15559	AIR SHUTTER - LPG
12	R7106	BURNER
13	15608	INNER BOTTOM ASSEMBLY
14	15512	PILOT BRACKET
15	R3631	PILOT ASSEMBLY - NAT
15	R3630	PILOT ASSEMBLY - LPG
16	15609	GLASS ASSEMBLY
17	15502	GLASS FRAME
18	15553	REAR LOG SUPPORT ASSEMBLY

PARTS LIST

Index No.	Part Number	Description
19	15483	INNER BODY
20	15515	SIDE SHIELDS
21	15607	DIVERTER BACK ASSEMBLY
22	15517	INNER TOP ASSEMBLY
23	15493	MOUNTING BRACKET - UPPER
24	R3768	ECO WIRE ASSEMBLY
25	R3981	ECO LIMIT SWITCH
26	15606	DIVERTER ASSEMBLY
27	11228	DIVERTER OUTLET ASSEMBLY
28	CI328	WIRE CHANNEL
29	CI326	SWITCH BOX
30	R3436	ON/OFF/REMOTE SWITCH
31	15643	REAR COVER ASSEMBLY
32	R7221	FRONT LOG
33	R7220	REAR LOG
34	R7222	TOP LOG
NS	R7295	WIRE ASSEMBLY
NS	CI253	MAGNET ASSEMBLY
NS	15610	TUBING - VALVE TO PILOT
NS	CI348	SWITCH BOX INSULATION

Click Part # To View
Price & Availability


30
29
28
31
27
26
25
23
24
23
22
21
20
20
19
18
34
33
32
15
14
11
10
9
8
12
16
13
3
4
2
3
7
17
6
1
5

CIBV-30-20