PARTS LIST

Index No.	Part Number	Description
1	WFA115	GASKET BASE PLATE
2	GW215	HEADER (GW25-2 & GW35-2)
3	GW155	INNER CASING (GW25-2)
3	GW156	INNER CASING (GW35-2)
4	GW147	DRAFT DIVERTER (GW25-2)
4	GW143	DRAFT DIVERTER (GW35-2)
5	GW221	COMBUSTION CHAMBER ASSEMBLY (GW25-2)
6	GW173	COMBUSTION CHAMBER ASSEMBLY (GW35-2)
7	GW022	BURNER PAN
8	R1155	ELECTRODE AND WIRE
9	R854	PIEZO IGNITOR
10	P8654	BURNER ORIFICE (GW25-2 LP)
10	P8643	BURNER ORIFICE (GW25-2 NAT)
10	P8652	BURNER ORIFICE (GW35-2 LP)
10	P8637	BURNER ORIFICE (GW35-2 NAT)
11	R206	NUT FOR ORIFICE FITTING
12	P104	ORIFICE FITTING
13	P103	NIPPLE
14	P112	UNION ASSEMBLY
15	R5246	VALVE (7000 MVRLC-LP)
15	R5245	VALVE (7000 MVRLC-NAT)
16	GW280	BURNER LP
16	GW117	BURNER NAT
17	R1203	PILOT LP
17	R1204	PILOT NAT
17	R1205	PILOT ORIFICE LP (NS)
17	R1206	PILOT ORIFICE NAT (NS)
18	R1054	THERMOPILE (GENERATOR)
19	GW200	PILOT TUBING W/FERRULES
20	GW020	HEAT SHIELD
21	GW041	OUTER CASING REAR SUPPORT LEFT
22	GW038	OUTER CASING REAR SUPPORT RIGHT
23	GW196	OUTER CASING
24	GWT087	CASING DOOR
25	R885	PLASTIC WASHERS
26	EL158	MAGNET FOR DOOR (NS) (TWO REQUIRED)
27	R734	MATCH HOLDER (NS)
28	R1226	WALL THERMOSTAT MILLIVOLT (NS)
29	R1568	REGULATOR NAT (NO LONGER AVAILABLE)
29	R1086	REGULATOR LP (NO LONGER AVAILABLE)
30	R1543	VENT SAFETY LIMIT SWITCH (GW25-2) (NS)
30	R1662	VENT SAFETY LIMIT SWITCH (GW35-2) (NS)
31	R1545	WIRE HARNESS VENT SAFETY (GW25-2 & GW35-2) (NS)
32	GW157	TOP SHIELD (NS)

CONVERSION KIT		
TO LP	TO NATURAL	MODEL NUMBER
682261	682152	GW25-2
682262	682153	GW35-2



GW-25-2 & 35-2

Click Part # To View Price & Availability

PARTS LIST

Index No.	Part Number	Description
1	WFA115	GASKET - BASE PLATE
2	GW215	HEADER
3	GW155	INNER CASING (GW25)
3	GW156	INNER CASING (GW35)
4	GW228	DRAFT DIVERTER (GW25)
4	GW234	DRAFT DIVERTER (GW35)
5	GW221	COMBUSTION CHAMBER ASSEMBLY (GW25)
6	GW173	COMBUSTION CHAMBER ASSEMBLY (GW35)
7	GW022	BURNER PAN
8	R1155	ELECTRODE AND WIRE
9	R854	PIEZO IGNITOR
10	P8654	BURNER ORIFICE (GW25 LP)
10	P8643	BURNER ORIFICE (GW25 NAT)
10	P8652	BURNER ORIFICE (GW35 LP)
10	P8637	BURNER ORIFICE (GW35 NAT)
11	R206	NUT FOR ORIFICE FITTING
12	P104	ORIFICE FITTING
13	P103	NIPPLE
14	P112	UNION ASSEMBLY
15	R5246	VALVE (7000 MVRLC-LP)
15	R5245	VALVE (7000 MVRLC-NAT)
16	GW280	BURNER LP
16	GW117	BURNER NAT
17	R1203	PILOT LP
17	R1204	PILOT NAT
17	R1205	PILOT ORIFICE (LP) (NS)
17	R1206	PILOT ORIFICE (NAT) (NS)
18	R1054	THERMOPILE (GENERATOR)
19	GW200	PILOT TUBING W/ FERRULES
20	GW020	HEAT SHIELD
21	GW041	OUTER CASING REAR SUPPORT LEFT
22	GW038	OUTER CASING REAR SUPPORT RIGHT
23	GW196	OUTER CASING
24	GWT087	CASING DOOR
25	R885	PLASTIC WASHERS
26	EL158	MAGNET FOR DOOR
27	R734	MATCH HOLDER (NS)
28	R1226	WALL THERMOSTAT MILLIVOLT (NS)
29	R1568	REGULATOR NAT (NO LONGER AVAILABLE)
29	R1086	REGULATOR LP (NO LONGER AVAILABLE)
30	R1767	VENT SAFETY LIMIT SWITCH (GW25) (NS)
30	R1768	VENT SAFETY LIMIT SWITCH (GW35) (NS)
31	R1545E	VENT SAFETY LIMIT WIRE (NS)
32	GW157	TOP SHIELD (NS)

CONVERSION KIT

TO LP	TO NATURAL	MODEL NUMBER
682261	682152	GW25-3
682262	682153	GW35-3



GW-25-3
GW-35-3

Click Part # To View Price & Availability

PARTS LIST

Index No.	Part Number	Description
1	WFA115	GASKET - BASE PLATE
2	GW215	HEADER
3	GW157	TOP SHIELD
4	GW155	INNER CASING (GW25/35-4)
4	GW256	INNER CASING (GW25/35-5)
5	GW228	DRAFT DIVERTER (GW25)
5	GW234	DRAFT DIVERTER (GW35)
6	R1767	VENT SAFETY LIMIT SWITCH (GW25)
6	R1768	VENT SAFETY LIMIT SWITCH (GW35)
7	GW221	COMBUSTION CHAMBER ASSEMBLY (GW25)
7	GW173	COMBUSTION CHAMBER ASSEMBLY (GW35)
8	GW020	HEAT SHIELD
9	GW041	OUTER CASING REAR SUPPORT LEFT
10	GW038	OUTER CASING REAR SUPPORT RIGHT
11	GW196	OUTER CASING
12	EL158	MAGNET FOR DOOR (2 REQUIRED)
13	GWT087	CASING DOOR
14	R885	NYLON WASHER (2 REQUIRED)
15	P8654	BURNER ORIFICE (GW25 LP)
15	P8643	BURNER ORIFICE (GW25 NATURAL)
15	P8652	BURNER ORIFICE (GW35 LP)
15	P8637	BURNER ORIFICE (GW35 NATURAL)
16	P104	ORIFICE FITTING
17	P103	MANIFOLD NIPPLE
18	P112	UNION ASSEMBLY
19	GW271	VALVE (REPLACEMENT KIT LP)
19	GW270	VALVE (REPLACEMENT KIT NATURAL)
20	GW239	VALVE BRACKET
21	R1203	PILOT (LP)
21	R1204	PILOT (NATURAL)
21	R1205	PILOT ORIFICE (LP) (NS)
21	R1206	PILOT ORIFICE (NATURAL) (NS)
22	R1054	THERMOPILE (GENERATOR)
23	R1155	ELECTRODE AND WIRE
24	GW280	BURNER LP
24	GW117	BURNER NAT
25	R854	PIEZO IGNITOR
26	GW022	BURNER PAN
27	R206	NUT FOR ORIFICE FITTING
28	GW240	PILOT TUBING (NS) W/ FERRULES
29	R734	MATCH HOLDER (NS)
30	R1545F	VENT SAFETY LIMIT WIRE (NS)
31	R1226	WALL THERMOSTAT MILLIVOLT (NS)

CONVERSION KIT

TO NATURAL	MODEL NUMBER
682177	GW25-4 & 5
682178	GW35-4 & 5



GW-25-4 & 5
GW-35-4 & 5

Click Part # To View Price & Availability

PARTS LIST

Index No.	Part Number	Description
1	WFA115	GASKET BASE PLATE
2	GW215	HEADER
3	GW157	TOP SHIELD
4	GW256	INNER CASING
5	GW228	DRAFT DIVERTER (GW25-6 ONLY)
5	GW234	DRAFT DIVERTER (GW35-6 ONLY)
6	R1767	VENT SAFETY LIMIT SWITCH (GW25-6 ONLY)
6	R1768	VENT SAFETY LIMIT SWITCH (GW35-6 ONLY)
7	GW221	COMBUSTION CHAMBER (GW25-6 ONLY)
7	GW173	COMBUSTION CHAMBER (GW35-6 ONLY)
8	GW020	HEAT SHIELD
9	GW041	REAR CASING SUPPORT - LEFT
10	GW038	REAR CASING SUPPORT - RIGHT
11	GW196	OUTER CASING
12	EL158	MAGNET FOR DOOR (2 REQUIRED)
13	GWT087	CASING DOOR
14	R885	NYLON WASHER (2 REQUIRED)
15	P8654	BURNER ORIFICE (GW25-6 L.P. GAS ONLY)
15	P8643	BURNER ORIFICE (GW25-6 NAT. GAS ONLY)
15	P8652	BURNER ORIFICE (GW35-6 L.P. GAS ONLY)
15	P8637	BURNER ORIFICE (GW35-6 NAT. GAS ONLY)
16	P104	ORIFICE FITTING
17	P103	MANIFOLD NIPPLE
18	P112	UNION ASSEMBLY
19	R5246	GAS VALVE (7000MVRLC L.P. GAS ONLY)
19	R5245	GAS VALVE (7000MVRLC NAT. GAS ONLY)
20	GW193	VALVE BRACKET
21	R1203	PILOT L.P.
21	R1204	PILOT NAT.
22	R1054	THERMOPILE (GENERATOR)
23	R1155	ELECTRODE AND WIRE
24	GW280	BURNER L.P.
24	GW117	BURNER NAT.
25	R854	PIEZO W/NUT (PRE "P" SERIAL NUMBER)
25	R2708	PIEZO PUSH-IN TYPE ("P" SERIAL NUMBER & LATER)
26	GW022	BURNER PAN
27	R206	NUT FOR ORIFICE FITTING
NS	R1205	PILOT ORIFICE (HONEYWELL .008 L.P. GAS ONLY)
NS	R1206	PILOT ORIFICE (HONEYWELL .012 NAT. GAS ONLY)
NS	GW200	PILOT TUBING
NS	R734	MATCH HOLDER
NS	R1545D	VENT SAFETY LIMIT WIRE
NS	R1226	MILLIVOLT WALL THERMOSTAT
NS	R1224	REMOTE BULB THERMOSTAT

Conversion Kit

To LP	To Natural	Model Number
682261	682152	GW25-6
682262	682153	GW35-6



GW-25-6
GW-35-6

Click Part # To View Price & Availability

PARTS LIST

Index No.	Part Number	Description
1	GWT045	SHADOW TRIM (2 REQUIRED)
2	GWT080	OUTER CASING ASSEMBLY
3	GWT164	CASING BRACKET
4	GWT164	CASING BRACKET
5	EL158	MAGNET (2 REQUIRED)
6	GWT087	CASING DOOR ASSEMBLY
7	R885	NYLON WASHER (2 REQUIRED)
8	R3039	ELECTRODE AND WIRE ASSEMBLY
9	GWT021	PILOT BRACKET
10	R1054	THERMOPILE
11	R3035	PILOT - LPG
11	R3034	PILOT - NAT
12	DV064	COVER PLATE
13	GWT009	BURNER COMPARTMENT FRONT - GWT25-1 NAT
13	GWT010	BURNER COMPARTMENT FRONT - GWT25-1 LPG
13	GWT007	BURNER COMPARTMENT FRONT - GWT35-1 NAT
13	GWT008	BURNER COMPARTMENT FRONT - GWT35-1 LPG
14	GWT006	INLET PLATE - GWT25-1 NAT
14	GWT005	INLET PLATE - GWT35-1 NAT
15	GWT014	AIR SHUTTER FRONT - GWT25-1
15	GWT011	AIR SHUTTER FRONT - GWT35-1
16	GWT016	AIR SHUTTER BOTTOM - GWT25-1 NAT
16	GWT054	AIR SHUTTER BOTTOM - GWT25-1 LPG
16	GWT013	AIR SHUTTER BOTTOM - GWT35-1 NAT
16	GWT049	AIR SHUTTER BOTTOM - GWT35-1 LPG
17	GWT015	AIR SHUTTER REAR - GWT25-1
17	GWT012	AIR SHUTTER REAR - GWT35-1
18	P8855	BURNER ORIFICE - GWT25-1 NAT (3 REQUIRED)
18	P8866	BURNER ORIFICE - GWT25-1 LPG (3 REQUIRED)
18	P8854	BURNER ORIFICE - GWT35-1 NAT (4 REQUIRED)
18	P8866	BURNER ORIFICE - GWT35-1 LPG (4 REQUIRED)
19	R3031	BURNER (GWT25-1 - 3 REQUIRED) (GWT35-1 - 4 REQUIRED)
20	R2708	PIEZO IGNIITOR
21	GWT022	PIEZO BRACKET
22	R5245	GAS VALVE - NAT
22	R5246	GAS VALVE - LPG
23	GWT070	BURNER BRACKET ASSEMBLY - GWT25-1
23	GWT073	BURNER BRACKET ASSEMBLY - GWT35-1
24	GWT068	EXCHANGER ASSEMBLY - GWT25-1
24	GWT069	EXCHANGER ASSEMBLY - GWT35-1
25	GWT077	HEAT SHIELD
26	GWT020	FRONT SHIELD
27	R3239	VENT SAFETY SWITCH - GWT25-1
27	R3045	VENT SAFETY SWITCH - GWT35-1
28	R3038-A	ECO LEAD ASSEMBLY
29	GWT065	DIVERTER ASSEMBLY - GWT25-1
29	GWT066	DIVERTER ASSEMBLY - GWT35-1
30	GWT064	INNER CASING ASSEMBLY
31	GWT083	HEADER ASSEMBLY (INCLUDES NO. 32, GASKET)
32	WFA-115	HEADER GASKET
NS	GWT121	PILOT TUBING - GWT25-1
NS	GWT076	PILOT TUBING - GWT35-1
NS	R1089	PILOT ORIFICE (HONEYWELL .009 LPG ONLY)
NS	R1081	PILOT ORIFICE (HONEYWELL .014 NAT ONLY)
NS	R1226	MILLIVOLT WALL THERMOSTAT
NS	R1224	RB THERMOSTAT



GWT-25-1
GWT-35-1

Click Part # To View Price & Availability

CONVERSION KIT

TO LP	TO NATURAL	MODEL NUMBER
GWT157	GWT159	GWT25-1
GWT158	GWT160	GWT35-1

PARTS LIST

Index No.	Part Number	Description
1	WFA-115	HEADER GASKET
2	GWT172	HEADER ASSEMBLY(INCLUDES NO. 1, GASKET)
3	GWT182	INNER CASING ASSEMBLY
4	GWT065	DIVERTER ASSEMBLY - GWT25-2
4	GWT066	DIVERTER ASSEMBLY - GWT35-2
5	R3239	VENT SAFETY SWITCH - GWT25-2
5	R3045	VENT SAFETY SWITCH - GWT35-2
6	R3038-A	ECO LEAD ASSEMBLY
7	GWT020	FRONT SHIELD
8	GWT077	HEAT SHIELD
9	GWT068	EXCHANGER ASSEMBLY - GWT25-2
9	GWT069	EXCHANGER ASSEMBLY - GWT35-2
10	GWT070	BURNER BRACKET ASSEMBLY - GWT25-2
10	GWT073	BURNER BRACKET ASSEMBLY - GWT35-2
11	R5245	GAS VALVE - NAT
11	R5246	GAS VALVE - LPG
12	R3031	BURNER (GWT25-2 - 3 REQUIRED) (GWT35-2 - 4 REQUIRED)
13	P8855	BURNER ORIFICE - GWT25-2 NAT (3 REQUIRED)
13	P8866	BURNER ORIFICE - GWT25-2 LPG (3 REQUIRED)
13	P8854	BURNER ORIFICE - GWT35-2 NAT (4 REQUIRED)
13	P8866	BURNER ORIFICE - GWT35-2 LPG (4 REQUIRED)
14	GWT015	AIR SHUTTER REAR - GWT25-2 LPG
14	GWT012	AIR SHUTTER REAR - GWT35-2 LPG
15	GWT054	AIR SHUTTER BOTTOM - GWT25-2 LPG
15	GWT049	AIR SHUTTER BOTTOM - GWT35-2 LPG
16	GWT014	AIR SHUTTER FRONT - GWT25-2 LPG
16	GWT011	AIR SHUTTER FRONT - GWT35-2 LPG
17	GWT010	BURNER COMPARTMENT FRONT - GWT25-2
17	GWT008	BURNER COMPARTMENT FRONT - GWT35-2
18	DV064	COVER PLATE
19	R3035	PILOT - LPG
19	R3034	PILOT - NAT
20	GWT021	PILOT BRACKET
21	R1054	THERMOPILE
22	GWT186	CASING BRACKET
23	GWT177	CASING FRONT ASSEMBLY
24	CI253	MAGNET (2 REQUIRED)
25	GWT087	CASING DOOR ASSEMBLY
26	R885	NYLON WASHER (2 REQUIRED)
NS	GWT121	PILOT TUBING - GWT25-2
NS	GWT076	PILOT TUBING - GWT35-2
NS	R1089	PILOT ORIFICE (HONEYWELL .009 LPG ONLY)
NS	R1081	PILOT ORIFICE (HONEYWELL .014 NAT ONLY)
NS	GWT190	HARDWARE PACKAGE



GWT-25-2
GWT-35-2

Click Part # To View Price & Availability

CONVERSION KIT

TO LP	TO NATURAL	MODEL NUMBER
11564	11561	GWT25-2
11565	11562	GWT35-2

PARTS LIST

Index No.	Part Number	Description
1	WFA115	GASKET - BASE PLATE
2	GW168	HEADER
3	GW161	INNER CASING
4	GW147	DRAFT DIVERTER (FRONT)
4	GW180	DRAFT DIVERTER (BACK)
5	GW272	COMBUSTION CHAMBER W/CARRYOVER SHIELD
6	GW058	BURNER PAN
7	R1155	ELECTRODE AND WIRE
8	R854	PIEZO IGNITOR
9	P8654	BURNER ORIFICE (LP)
9	P8644	BURNER ORIFICE (NAT)
10	P157	MANIFOLD ASSEMBLY
11	R5246	VALVE (7000 MVRLC-LP)
11	R5245	VALVE (7000 MVRLC-NAT)
12	GW280	BURNER FRONT LP
12	GW117	BURNER FRONT NAT
13	GW281	BURNER REAR LP
13	GW267	BURNER REAR NAT
14 A	R1203	PILOT LP
14 B	R1204	PILOT NAT
14 C	R1205	PILOT ORIFICE (LP) (NS)
14 D	R1206	PILOT ORIFICE (NAT) (NS)
15	R1054	THERMOPILE (GENERATOR)
16	GW202	PILOT TUBING W/ FERRULES
17	GW266	CARRYOVER SHIELD
18	R2504	1/4CC. X 1/8NPT STRAIGHT CONNECTOR (NS)
19	GW066	TUBING CARRYOVER (NS)
20	R1191	CARRYOVER ORIFICE HOLDER (NS)
21	R1843-A	CARRYOVER ORIFICE LP (NS)
21	R1844-A	CARRYOVER ORIFICE NAT (NS)
22	R1875	TUBING CARRYOVER (T-BURNER)
23	GW020	HEAT SHIELD
24	GW041	OUTER CASING REAR SUPPORT LEFT (2)
25	GW038	OUTER CASING REAR SUPPORT RIGHT (2)
26	GW196	OUTER CASING
27	GWT087	CASING DOOR
28	R885	PLASTIC WASHERS
29	EL158	MAGNET FOR DOOR (NS) (4 REQUIRED)
30	R734	MATCH HOLDER (NS)
31	R1226	WALL THERMOSTAT MILLIVOLT (NS)
32	R1568	REGULATOR NAT (NO LONGER AVAILABLE)
32	R1086	REGULATOR LP (NO LONGER AVAILABLE)
33	R1543	VENT SAFETY LIMIT SWITCH (NS)
34	R1545	WIRE HARNESS VENT SAFETY (NS)
35	GW157	TOP SHIELD (NS)
36	GW074	PRIVACY SHIELD (NS)

CONVERSION KIT	
TO LP	TO NATURAL
682263	682154



GW-50-1 & 2

Click Part # To View Price & Availability

PARTS LIST

Index No.	Part Number	Description
1	WFA-115	GASKET BASEPLATE
2	GW168	HEADER
3	GW157	TOP SHIELD (2 REQUIRED)
4	GW092	HEADER GASKET
5	GW074	PRIVACY SHIELD
6	GW161	INNER CASING
7	GW228	DRAFT DIVERTER (2 REQUIRED)
8	R1769	VENT SAFETY LIMIT SWITCH
9	GW272	COMBUSTION CHAMBER (2 REQUIRED) W/CARRYOVER SHIELD
10	GW020	HEAT SHIELD (2 REQUIRED)
11	GW041	REAR CASING SUPPORT LEFT (2 REQUIRED)
12	GW038	REAR CASING SUPPORT RIGHT (2 REQUIRED)
13	GW196	OUTER CASING (2 REQUIRED)
14	EL158	MAGNET WITH ADHESIVE BACKING (4 REQUIRED)
15	GWT087	CASING DOOR (2 REQUIRED)
16	R885	NYLON WASHER (4 REQUIRED)
17	GW274	CARRYOVER SHIELD ASSEMBLY
18	R1875	CARRYOVER TUBE (T-BURNER)
19	R1844A	CARRYOVER ORIFICE (NAT. GAS)
19	R1843A	CARRYOVER ORIFICE (LP GAS)
20	R1191	CARRYOVER ORIFICE HOLDER
21	R206	NUT FOR MANIFOLD (2 REQUIRED)
22	P8644	BURNER ORIFICE (NAT. GAS ONLY) (2 REQUIRED)
22	P8654	BURNER ORIFICE (LP GAS ONLY) (2 REQUIRED)
23	P157	MANIFOLD
24	R5246	VALVE LP (ROBERTSHAW 7000 MVRLC) GW50-3
24	R5245	VALVE NAT. (ROBERTSHAW 7000 MVRLC) GW50-3
24	GW270	VALVE (REPLACEMENT KIT NAT. GAS) GW50-4
24	GW271	VALVE (REPLACEMENT KIT LP GAS) GW50-4
25	R1203	PILOT WITH ORIFICE (LP GAS)
25	R1204	PILOT WITH ORIFICE (NAT. GAS)
26	R1054	THERMOPILE (GENERATOR)
27	R1155	ELECTRODE AND WIRE
28	GW280	BURNER FRONT LP
28	GW117	BURNER FRONT NAT
29	R854	PIEZO W/NUT (PRE "P" SERIAL NUMBER)
29	R2708	PIEZO PUSH-IN TYPE ("P" SERIAL NUMBER & LATER)
30	GW058	BURNER PAN
31	GW281	BURNER REAR LP
31	GW267	BURNER REAR NAT
32	R1205	PILOT ORIFICE (LP GAS) (NS)
32	R1206	PILOT ORIFICE (NAT. GAS) (NS)
33	GW241	PILOT TUBING W/FERRULES (NS) GW50-4
33	GW202	PILOT TUBING W/ FERRULES (NS) GW50-3
34	GW066	CARRYOVER TUBING (NS)
35	R2504	1/4 CC. X 1/8 NPT STRAIGHT CONNECTOR (NS)
36	R1545E	VENT SAFETY LIMIT WIRE (NS)
37	R734	MATCH HOLDER (NS)
38	R1226	MILLIVOLT WALL THERMOSTAT (NS)
39	R1568	REGULATOR NAT. (NS) GW50-3 (NO LONGER AVAILABLE)
39	R1086	REGULATOR LP (NS) GW50-3 (NO LONGER AVAILABLE)



GW-50-3 & 4

Click Part # To View Price & Availability

CONVERSION KIT

TO LP	TO NATURAL	MODEL NUMBER
	682179	GW50-4
GW278	GW279	GW50-3

PARTS LIST

Index No.	Part Number	Description
1	WFA-115	HEADER GASKET
2	GWT102	HEADER ASSEMBLY (INCLUDES NO. 1, GASKET)
3	GWT093	INNER CASING ASSEMBLY
4	GWT151	FRONT DIVERTER ASSEMBLY
4	GWT163	REAR DIVERTER ASSEMBLY
5	GWT045	SHADOW TRIM (4 REQUIRED)
6	GWT080	OUTER CASING ASSEMBLY (2 REQUIRED)
7	GWT020	FRONT SHIELD (2 REQUIRED)
8	GWT077	HEAT SHIELD (2 REQUIRED)
9	GWT164	CASING BRACKET - (2 REQUIRED)
10	GWT164	CASING BRACKET - (2 REQUIRED)
11	EL158	MAGNET (4 REQUIRED)
12	R885	NYLON WASHER (4 REQUIRED)
13	GWT087	CASING DOOR ASSEMBLY (2 REQUIRED)
14	DV064	COVER PLATE (2 REQUIRED)
15	GWT008	BURNER COMPARTMENT FRONT - LPG (2 REQUIRED)
15	GWT048	BURNER COMPARTMENT FRONT - NAT (2 REQUIRED)
16	GWT006	INLET PLATE - NAT (2 REQUIRED)
17	GWT094	EXCHANGER ASSEMBLY - FRONT
18	R3036	PILOT - NAT
18	R3037	PILOT - LPG
19	R1054	THERMOPILE
20	R3039	ELECTRODE AND WIRE ASSEMBLY
21	GWT096	BURNER BRACKET ASSEMBLY
22	R5245	GAS VALVE - NAT
22	R5246	GAS VALVE - LPG
23	GWT015	AIR SHUTTER REAR (2 REQUIRED)
24	GWT014	AIR SHUTTER FRONT (2 REQUIRED)
25	GWT054	AIR SHUTTER BOTTOM - LPG (2 REQUIRED)
25	GWT016	AIR SHUTTER BOTTOM - NAT (2 REQUIRED)
26	P8855	BURNER ORIFICE - NAT (6 REQUIRED)
26	P8866	BURNER ORIFICE - LPG (6 REQUIRED)
27	R3031	BURNER (6 REQUIRED)
28	R2708	PIEZO IGNIITOR
29	GWT095	EXCHANGER ASSEMBLY - REAR
30	R3038A	ECO LEAD ASSEMBLY
31	R3046	VENT SAFETY SWITCH
NS	GWT099	PILOT TUBING
NS	R3178	PILOT ORIFICE (HONEYWELL K14 .014 LPG ONLY)
NS	R3179	PILOT ORIFICE (HONEYWELL A26 .026 NAT ONLY)
NS	R734	MATCH HOLDER
NS	R1226	MILLIVOLT WALL THERMOSTAT
NS	R1224	RB THERMOSTAT



GWT-50-1

Click Part # To View Price & Availability

CONVERSION KIT

TO LP GWT161

TO NATURAL GWT162

PARTS LIST

Index No.	Part Number	Description
1	WFA115	HEADER GASKET
2	GWT175	HEADER ASSEMBLY (INCLUDES NO. 1, GASKET)
3	GWT184	INNER CASING ASSEMBLY
4	GWT151	DIVERTER ASSEMBLY (2 REQUIRED)
5	GWT020	FRONT SHIELD (2 REQUIRED)
6	GWT077	HEAT SHIELD (2 REQUIRED)
7	GWT177	OUTER CASING ASSEMBLY (2 REQUIRED)
8	GWT186	CASING BRACKET (4 REQUIRED)
9	GWT087	CASING DOOR ASSEMBLY (2 REQUIRED)
10	R885	NYLON WASHER (4 REQUIRED)
11	CI253	MAGNET (4 REQUIRED)
12	DV064	COVER PLATE (2 REQUIRED)
13	GWT008	BURNER COMPARTMENT FRONT (2 REQUIRED)
14	R3046	VENT SAFETY SWITCH
15	R3038-A	ECO LEAD ASSEMBLY
16	GWT095	EXCHANGER ASSEMBLY - REAR
17	GWT094	EXCHANGER ASSEMBLY - FRONT
18	R3036	PILOT - NAT
18	R3037	PILOT - LPG
19	R1054	THERMOPILE
20	GWT096	BURNER BRACKET ASSEMBLY
21	R5245	GAS VALVE - NAT
21	R5246	GAS VALVE - LPG
22	R3031	BURNER (6 REQUIRED)
23	P8855B	BURNER ORIFICE - NAT (6 REQUIRED)
23	P8866C	BURNER ORIFICE - LPG (6 REQUIRED)
24	GWT014	AIR SHUTTER FRONT - LPG (2 REQUIRED)
25	GWT015	AIR SHUTTER REAR - LPG (2 REQUIRED)
26	GWT054	AIR SHUTTER BOTTOM - LPG (2 REQUIRED)
NS	GWT099	PILOT TUBING
NS	R3178	PILOT ORIFICE (HONEYWELL K14 .014 LPG ONLY)
NS	R3179	PILOT ORIFICE (HONEYWELL A26 .026 NAT ONLY)
NS	R734	MATCH HOLDER
NS	GWT190	HARDWARE PACKAGE (2 REQUIRED)



GWT-50-2

Click Part # To View Price & Availability

CONVERSION KIT

To LP	To Natural
11566	11563